


Instruction manual of photo table (B-1020)

Table of content

Ax2	2 supporting poles A (\varnothing 25cm) ,pole length 74cm	Gx2	2front supporting poles \varnothing 25cm , pole length 20cm
Bx2	2 CLD-15	Hx8	8 white plastic clippers (RL-110)
CX2	2 poles (\varnothing 25cm) , pole length 70cm	Ix2	2 CL-35 (with iron heads)
Dx2	2 poles for fixing(\varnothing 25cm) ,pole length 101cm	Jx1	1 PP plastic sheet (100x200cm)
Ex2	2 horizontal poles (\varnothing 25cm) , pole length 84 cm	Kx2	2 supporting poles (\varnothing 25cm) , pole length 74cm
Fx2	2 horizontal poles for the bottom (\varnothing 25cm) , pole length 94cm	Lx2	2 horizontal poles for the bottom ,pole length 70cm



Instruction manual of photo table (B-1020)

Precautions of setting up the

photo table

1. Step1 – connect 2 poles A and 2 poles K with 2 poles F and 2 poles L to form a rectangular shape.
2. Step 2 – place 2 poles E horizontally on poles A and poles K and fasten them.
3. Step 3 – plug 2 supporting poles G onto poles A and fasten it.
4. Step 4 – plug a pole to fix the photo table onto the ends of both poles G.
5. Step 5 – plug 2 (CLD-15) “B” onto the ends of both poles E. Adjust them to a needed angle and fasten them with the handle.
6. Step 6 – connect 2 poles C to the ends of “B” (CLD-15) and fasten them afterwards.
7. Step 7 – Connect pole D with the ends of both poles C and fasten it.
8. 2 clippers “I” (CL-35) with iron heads are provided for the use of flashes or lighting. Place them according to your needs.
9. Place the upper end of the PP Plastic sheet “J” onto the very top of the photo table. Fix it with 8 white plastic clippers “H” provided. Position of clippers can be adjusted according to needs while it is best to place them evenly.

